

## Play Mode Combos

---

### Menus

Settings Menu: Up1 + A1 + B1  
Synth Menu: Select1 + A1 + B1

### Menu Notes:

- Up / Down to select Option
  - Left / Right to edit Option
  - Press Select to switch between Menus
  - Press Start to return to Play Mode
- 

### Tone Banks

Select4 + A4 = Synth  
Select 4 + B4 = Drums

---

### Noise Banks

Select3 + A3 = Bank A  
Select3 + B3 = Bank B

---

### Shortcut Mode

Down1 + A1 + B1

### Shortcut Mode Notes:

- Sound is muted in Shortcut Mode
  - Press Start to return to Play Mode
- 

## Shortcut Mode Combos

---

### SWEEP 1

Start4 + Select2 = rate 25%  
Start4 + Start2 = rate 50%  
Start4 + B2 = rate 75%  
Start4 + A2 = rate 100%  
Start4 + Up2 = sweep1 Up  
Start4 + Down2 = sweep1 Down

---

### SWEEP 2

Select4 + Select2 = rate 25%  
Select4 + Start2 = rate 50%  
Select4 + B2 = rate 75%  
Select4 + A2 = rate 100%  
Select4 + Up2 = sweep2 Up  
Select4 + Down2 = sweep2 Down

---

### Root Note

Down2 + Up3 = C  
Down2 + Down3 = D  
Down2 + Left3 = E  
Down2 + Right3 = F  
Down2 + Select3 = G  
Down2 + Start3 = A  
Down2 + B3 = B  
Down2 + A3 = Half Step Up (for #'s)

---

### Scales

Up2 + Up3 = Major  
Up2 + Down3 = Minor  
Up2 + Left3 = Harmonic  
Up2 + Right3 = Phrygian  
Up2 + Select3 = Dorian  
Up2 + Start3 = Lydian  
Up2 + B3 = Locrian  
Up2 + A3 = Mixolydian

---

### ARP Rate

Right4 + Up2 = 30%  
Right4 + Down2 = 40%  
Right4 + Left2 = 50%  
Right4 + Right2 = 60%  
Right4 + Select2 = 70%  
Right4 + Start2 = 80%  
Right4 + B2 = 90%  
Right4 + A2 = 100%

---

### ARP Interval1

Up4 + Up2 = Unison  
Up4 + Down2 = 2nd  
Up4 + Left2 = 3rd  
Up4 + Right2 = 4th  
Up4 + Select2 = 5th  
Up4 + Start2 = 6th  
Up4 + B2 = 7th  
Up4 + A2 = Octave

---

### ARP Interval2

Down4 + Up2 = Unison  
Down4 + Down2 = 2nd  
Down4 + Left2 = 3rd  
Down4 + Right2 = 4th  
Down4 + Select2 = 5th  
Down4 + Start2 = 6th  
Down4 + B2 = 7th  
Down4 + A2 = Octave

---

### ARP Voice

Right4 + Start4 = Both (Sq. & Tri.)  
Right4 + B4 = Triangle  
Right4 + A4 = Square

---

### Chord1 Triangle

A4 + A3 = On  
A4 + B3 = Off

---

### Chord1 Interval

A4 + Up2 = Unison  
A4 + Down2 = 2nd  
A4 + Left2 = 3rd  
A4 + Right2 = 4th  
A4 + Select2 = 5th  
A4 + Start2 = 6th  
A4 + B2 = 7th  
A4 + A2 = Octave

---

### Chord2 Triangle

B4 + A3 = On  
B4 + B3 = Off

---

### Chord2 Interval

B4 + Up2 = Unison  
B4 + Down2 = 2nd  
B4 + Left2 = 3rd  
B4 + Right2 = 4th  
B4 + Select2 = 5th  
B4 + Start2 = 6th  
B4 + B2 = 7th  
B4 + A2 = Octave

---

### Decay Rate

Left4 + Right2 = Off  
Left4 + Select2 = 25%  
Left4 + Start2 = 50%  
Left4 + B2 = 75%  
Left4 + A2 = Infinity

---